



PROCAD
SPOOLCAD®

Setup Maintenance User Guide

© Copyright 2019, PROCAD Software. All rights reserved.

The contents of this document are the property of PROCAD Software, and are subject to change without notice. No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language, without the written permission of PROCAD Software

PROCAD Software
12 Elbow River Road
Calgary, Alberta
Canada, T3Z 2V2
www.procad.com

Trademarks


This manual makes reference to the following products. These products are registered trademarks of their manufacturers:

- ® AutoCAD is a registered trademark of Autodesk, Inc.
- ™ DWG is a trademark of Autodesk, Inc.
- ® Windows is a registered trademark of Microsoft Corporation
- ™ SQL Server is a trademark of Microsoft Corporation
- ® Pentium is a registered trademark of Intel Corporation
- ™ ISOGEN is a trademark of Alias Ltd.
- ® Weldolet, ® Thredolet, ® Sockolet, and ® Elbolet, are registered trademarks of Bonney Forge
- ® SPOOLCAD and PROCAD 3DSMART are registered trademarks of PROCAD Software

Other products mentioned are trademarks of their respective companies.

Table of Contents

Using Setup Maintenance	1
Introduction	1
Procedures	1
Opening Setup Maintenance.....	1
Mapping Configuration Paths to a New Location	2
Changing the Frequency of Update Checks	3
Changing the Type of License	4
Change the Icon Sizes.....	5
Add File Paths to Trusted Path	6
Printing the Current Configurations	6
Install AutoCAD OEM	6
 Dialog Boxes	 7
Setup Maintenance Dialog Box	7
Manage Shortcuts Dialog Box.....	8
Change License Type Dialog Box.....	9
Browse for Folder Dialog Box	10




Mapping Configuration Paths to a New Location


It may be necessary after the initial installation of the software to relocate some of the files to a new location. This may occur due to server upgrades, or when the application is being moved from a standalone configuration to a networked configuration.

The procedure for remapping a configuration path is the same for the application path, the data files path, and the license path.

To map to a new configuration path...

1. Click the  button to the right of the path that you wish to modify.

2. The Browse For Folder Dialog box will appear. Navigate to the new location of the files by using the “+” and “-“ signs to the left of the folder names. Clicking the “+” will expand the selected folder and clicking the “-“ will collapse the selected folder.



3. Click the **OK** button to accept the highlighted folder as the new location.

Changing the Frequency of Update Checks

PROCAD Software releases updates to our websites to allow PROCAD SPOOLCAD users to have the latest improvements and fixes as soon as possible. Setup Maintenance will check the PROCAD website for updates according to the settings in this application.

To change the frequency of update checks...

1. Open the **Setup Maintenance** dialog box using the shortcut in the PROCAD SPOOLCAD or PROCAD SPOOLCAD+ folder.
2. To change the date of the next update, click the down arrow for the drop down box.



3. A calendar view will appear.




4. To change months, use the left and right arrows at the top of the dialog. Select a specific day by right clicking on the date in the calendar. This will also close the calendar dialog
5. Highlight the text box and type in the number of days between updates.
6. Click the **OK** button to close the Setup Maintenance application and accept the change.

Changing the Type of License

It may be necessary to transition between a standalone, or local, license, to a networked, or shared, license. This procedure is also available from within the License Manager application.


To change the type of license in use...

1. Open the **Setup Maintenance** dialog box using the shortcut in the PROCAD SPOOLCAD or PROCAD SPOOLCAD+ folder.
2. From the **Edit** menu, select the **Change License Install Type** command.
3. The License Type dialog box appears.



4. Select the type of license that you wish to use.

If you select **Workstation**, you will be prompted to enter the server name in the format @ServerName.



Click the **OK** button to close the Server Name dialog box.

5. If you select **Standalone**, the Browse for Folder Dialog box will appear. Navigate to the new location of the files by using the “+” and “-” signs to the left of the folder names. Clicking the “+” will expand the selected folder and clicking the “-” will collapse the selected folder.

Click the **OK** button to accept the highlighted folder as the new location.


6. Click the **OK** button to close the Setup Maintenance application and accept the change.

Change the Icon Sizes

The user can use this option to change the icon size from small to large and vice versa.

To change the icon size...


1. To change the icon size, click the down arrow for the drop-down box



2. Choose the small or large icon option.
3. Click the **OK** button to close the Setup Maintenance application and accept the change.

Add File Paths to Trusted Path

1. From the *Edit* menu, select the *Add File Paths to Trusted Path* command.
2. A confirmation message will appear to let you know the files has been added to the trusted path



Note: This only applies to **PROCAD 2D**. It does not apply to **PROCAD 2D+** products.

Printing the Current Configurations

1. From the *File* menu, select the *Print* command.
2. Select the printer you wish to utilize and print.

Install AutoCAD OEM

1. From the *Edit* menu, select the *Install AutoCAD OEM* command.
2. A browse for folder dialog box will appear.
3. Select the acad32 (32-bit system) or acad64 (64-bit system) to install the AutoCAD OEM.
4. The AutoCAD OEM will begin to install.

Note: This only applies to **PROCAD 2D+** products. This option is not active on **PROCAD 2D** products.

Dialog Boxes


Setup Maintenance Dialog Box



Use this dialog to:

- Change the location of PROCAD SPOOLCAD data files, licenses or application files.
- Change the frequency that PROCAD SPOOLCAD will check for updates.

To access this dialog box...


Open the **Setup Maintenance** dialog box using the shortcut in the PROCAD SPOOLCAD folder.



In this field...	Do this...
Program Path	The location of basic program files required on all computers, regardless of the location of the applications.
Application Path	The location of the application files.
Datafiles Path	The location of the data files. This includes specifications, dimensional data files, and standard settings.
License Path	The location of the software licenses. For networked licenses, this will be @ServerName.
Next Web Update Date	Set the next date that the software will check PROCAD's website for new updates.
Web Update Frequency	The frequency that the software will check PROCAD's website for new updates.
AutoCAD Session	This will allow you to choose the version of AutoCAD that you would like to use with PROCAD SPOOLCAD. This option does not apply to PROCAD SPOOLCAD+ application.
AutoCAD Profile	This will allow you to create the profile name that PROCAD SPOOLCAD will use.
Menu Icon Size	This will allow you to select the icon size in the software.
	Click to display the contents of the currently selected location for the programs, applications, data files or licenses.
	Click to open the Browse for Folder dialog box. Use this to change the location of the applications, data files, or licenses.
OK	Click to close this dialog box and save the changes made.
Cancel	Click to close this dialog box without saving changes made.
Help	Click to access Help for this dialog box.

Manage Shortcuts Dialog Box


In the *Setup Maintenance* dialog box, click the *Manage Shortcuts* command from the *Edit* menu.



In this field...	Do this...
Checkbox	Turn the checkbox on beside any applications that you wish to have a shortcut for. If you do not wish to have a shortcut for a given application, turn off the checkbox by clicking it.
OK	Click OK to close the dialog box and apply the change.
Cancel	Click cancel to discard the changes.

Change License Type Dialog Box

In the *Setup Maintenance* dialog box, click the *Change License Install Type* command from the *Edit* menu.



In this field...	Do this...
Radio button	Select which option you would like the license type to be.
OK	Click OK to close the dialog box and apply the change.
Cancel	Click cancel to discard the changes.

Browse for Folder Dialog Box

